

EN.**MURALS****MADE TO MEASURE****MADE IN EUROPE****19.7" / 50 cm PANEL WIDTH**

Instructions for use for non woven "N" and vinyl "V" murals.

PRODUCT DESCRIPTION

Each mural is packaged in two* independent rolls of panels each with a 19.7"/ 50 cm width:

PART 1/2 contains the odd panels.

PART 2/2 contains the even panels.

** If the mural is small, it will be packaged in one roll. If the mural is extremely large, it will be divided into more than 2 rolls.*

HOW TO PREPARE THE WALL

1. Check that the wall is clean, smooth, free from imperfections and dry. Strip all remaining wallpaper.
2. Eliminate colour differences or contrasts. The surface should be uniform in colour.

HOW TO INSTALL THE MURAL**

1. Tools: Scissors, cutter, cellulose wall covering glue (non woven), brush or roller, rubber spatula for wall coverings, cloth, bucket and a long ruler.
2. Extend the rolls and cut each panel just after its numeric footer (keep the number so as not to lose the order).
3. Arrange all the panels from left to right according to the numeric footers and lay all of them in front of the wall to be covered.
4. Check before the installation that the mural is complete and that each of the panels matches with the next.
5. Prepare the cellulose glue in a bucket following the manufacturer's instructions.
6. Apply the cellulose glue with a brush or roller only onto the wall and spread it evenly across the surface. To achieve an optimum adhesion, apply the glue to a slightly larger surface than the panel.
7. Apply the dry panels from left to right and from top to bottom, smoothing it down with a rubber wall covering spatula or a cloth to eliminate air bubbles.
8. Repeat this process until all panels are hung without overlapping the joints. With a damp cloth, softly remove glue leftovers.
9. Cut the remaining wall covering with a cutter, using a ruler to guide the cutter.

***Coordonné will not be held responsible for any incidence once the hanging process of the mural has begun.*

coordonnéwww.coordonne.es

FOLLOW US:  @COORDONNE  /COORDONNE  /COORDONNE

COORDONNÉ S.L. C/ MEXIC, 32, 08004, BARCELONA, SPAIN / (+34) 93 322 73 14 / WWW.COORDONNE.ES / INFO@COORDONNE.ES



Instructions for use for non woven "N"
and vinyl "V" wallpaper rolls.

PRODUCT DESCRIPTION

Each roll contains 10 m/10.9 yd of continuous wallpaper made up of panels, each with a 50 cm/19.7"width.

HOW TO PREPARE THE WALL

1. Check that the wall is clean, smooth, free from imperfections and dry. Strip all remaining wallpaper.
2. Eliminate colour differences or contrasts. The surface should be uniform in colour.

HOW TO INSTALL THE WALLPAPER**

1. Tools: Scissors, cutter, cellulose wall covering glue (non-woven), brush or roller, rubber spatula for wall coverings, cloth, bucket and a long ruler.
2. Cut the first panel, using the height of the wall as a reference. Add 3 cm/1.18" at the top and the bottom. (Total height of the wall + 6 cm/2.36").
3. Prepare the cellulose glue in a bucket following the manufacturer's instructions.
4. Apply the cellulose glue with a brush or roller only onto the wall and spread it evenly across the surface. To achieve an optimum adhesion, apply the glue to a slightly larger surface than the panel.
5. Apply the first dry panel from left to right and from top to bottom, smoothing it down with a rubber wallcovering spatula or a cloth to eliminate air bubbles.
6. Check the match of the second panel before repeating the cutting process in nº 2, and before repeating the processes in nº 4 (applying the glue) and nº 5 (applying the wall covering and smoothing it down) as many times as needed to cover the wall. The joins of the wall covering panels should not overlap.
7. With a damp cloth, gently remove glue leftovers.
8. Cut the remaining wall covering with a cutter, using a ruler to guide the cutter.

***Coordonné will not be held responsible for any incidence once the hanging process of the rollpapers has begun.*

coordonné

www.coordonne.es

FOLLOW US:  @COORDONNE  /COORDONNE  /COORDONNE